

BLE Heart Rate Sensor

1.0

Features

- BLE Heart Rate Service support in the GATT Server role
- Simulating the Heart Rate data
- Reporting the workflow status through UART
- LED status indication

General Description

This example project demonstrates the BLE Heart Rate Sensor workflow. The project simulates Heart Rate data and performs communication with BLE enabled central/client device.

Development Kit Configuration

Default CY8CKIT-042 BLE Pioneer Kit configuration, Connect J2 pin P3[0] to J3 pin VREF.

Project Configuration

BLE Heart Rate Sensor Example Project




Figure 1. Top design schematic

The BLE component is configured as Heart Rate Sensor.




Figure 2. BLE configuration




Figure 3. GATT settings






Figure 4. GAP settings




Figure 5. GAP settings -> Advertisement settings






Figure 6. GAP settings -> Advertisement packet




Figure 7. GAP settings -> Scan response packet






Figure 8. GAP settings -> Peripheral preferred connection parameters




Figure 9. Security settings

Project Description

The project demonstrates the BLE workflow procedures like advertising, connecting, notifying Heart Rate data, Battery Level, etc.

The project is designed so there is no need to initiate any of mentioned actions manually – it automatically starts the BLE Stack, then, when the Stack is on (STACK_ON event is received), the advertising GAP procedure is initiated. The green LED is blinking while the device is advertising. Once connection request is received, it performs the connection procedure and provides its GATT database (configured in the GATT tab) for discovery process performed by client. The supported services are: Generic Access (GAP) and Attribute (GATT) Services, Heart Rate Service (HRS), Battery Service (BAS) and Device Information Service (DIS). When the Heart Rate notification is enabled by Client, the project starts to simulate all the Heart Rate Service related data (Heart Rate itself, Energy expended, RR-intervals). When the Battery Level notification is enabled by Client, the project starts to measure the voltage on Vref pin and notify the battery level. The WDT is used to timing the simulations, measurements and LED blinking. The blue LED turns on when the battery level value is less than 10%. The red LED is turned on after disconnection to indicate that no Client is connected to the device. On disconnection event the device immediately starts to advertising. When the device connects successfully, both red and green LEDs are turned off.

After 180 seconds timeout, if no central device has been connected, the Heart Rate Sensor stops advertising, a red LED is turned on indicating the disconnection state and the system enters into the hibernate mode. Press the mechanical button on CY8CKIT-042 BLE (SW2) to wake up the system and start re-advertising.

Expected Results

The project sends the Heart Rate and Battery Level notifications to the Central Client device which can show them for user. LEDs are blinking as described in Project Description section.

The project is intended to work in pair with the BLE Heart Rate Collector Example Project.

However, it can work with any other BLE-compatible device (e.g. phone, tablet) with appropriate software (with e.g. Android, iOS with installed application which supports Heart Rate Profile). For instance, you can use CySmart mobile app (<u>Android</u> / <u>iOS</u>) as Heart Rate Service client:








Figure 10. CySmart iOS app


Figure 11. CySmart Android app

Also, the Heart Rate Sensor can be used together with <u>CySmart app for Windows</u>. It is required to match the security settings between Heart Rate Sensor and CySmart Client and perform pairing (bonding) before any writing (enabling notifications etc.) into Server's GATT database. For further instructions on how to use CySmart application, see <u>CySmart User Guide</u>.

The simple example how to use CySmart Windows application as Heart Rate Service client is the next:

- Connect the CySmart BLE dongle to a USB port on the PC.
- Launch CySmart app and select connected dongle in the dialog window.
- Reset the development kit to start advertising by pressing SW1 button.
- Click Start Scan button to discover available devices.
- Select **Heart Rate Sensor** in the list of available devices and connect to it.
- Click **Pair**, then **Discover All Attributes**, and **Enable All Notifications** in CySmart app.

Observe the Heart Rate Measurement characteristic notifications with simulated data:



The details about the Heart Rate Service characteristic data structures are in the <u>HRS</u> Specification.

Optionally project can send log messages through UART. The example log is shown below:



BLE Heart Rate Sensor Example Project

EVT_STACK_ON

Start Advertisement with addr: 00a050000006

EVT_ADVERTISING

EVT_GATT_CONNECT_IND: attid 0, bdHandle 4

EVT_GAP_DEVICE_CONNECTED: 4
EVT_GATTS_XCNHG_MTU_REQ

EVT_GAP_AUTH_REQEVT_GAP_ENCRYPT_CHANGE: 1

EVT_GAP_AUTH_COMPLETE: security:2, bonding:1, ekeySize:10, authErr 0

Heart Rate Measurement Notification is Enabled

Heart Rate Notification is sent successfully, Heart Rate = 72

Heart Rate Notification is sent successfully, Heart Rate = 84

Heart Rate Notification is sent successfully, Heart Rate = 96

Heart Rate Notification is sent successfully, Heart Rate = 108

Heart Rate Notification is sent successfully, Heart Rate = 120

Heart Rate Notification is sent successfully, Heart Rate = 132

Heart Rate Notification is sent successfully, Heart Rate = 144



© Cypress Semiconductor Corporation, 2009-2016. The information contained herein is subject to change without notice. Cypress Semiconductor Corporation assumes no responsibility for the use of any circuitry other than circuitry embodied in a Cypress product. Nor does it convey or imply any license under patent or other rights. Cypress products are not warranted nor intended to be used for medical, life support, life saving, critical control or safety applications, unless pursuant to an express written agreement with Cypress. Furthermore, Cypress does not authorize its products for use as critical components in life-support systems where a malfunction or failure may reasonably be expected to result in significant injury to the user. The inclusion of Cypress products in life-support systems application implies that the manufacturer assumes all risk of such use and in doing so indemnifies Cypress against all charges.

PSOC® is a registered trademark, and PSOC Creator™ and Programmable System-on-Chin™ are trademarks of Cypress Semiconductor Cypr. All other trademarks or registered.

PSoC® is a registered trademark, and PSoC Creator™ and Programmable System-on-Chip™ are trademarks of Cypress Semiconductor Corp. All other trademarks or registered trademarks referenced herein are property of the respective corporations.

Any Source Code (software and/or firmware) is owned by Cypress Semiconductor Corporation (Cypress) and is protected by and subject to worldwide patent protection (United States and foreign), United States copyright laws and international treaty provisions. Cypress hereby grants to licensee a personal, non-exclusive, non-transferable license to copy, use, modify, create derivative works of, and compile the Cypress Source Code and derivative works for the sole purpose of creating custom software and or firmware in support of licensee product to be used only in conjunction with a Cypress integrated circuit as specified in the applicable agreement. Any reproduction, modification, translation, compilation, or representation of this Source Code except as specified above is prohibited without the express written permission of Cypress.

Disclaimer: CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Cypress reserves the right to make changes without further notice to the materials described herein. Cypress does not assume any liability arising out of the application or use of any product or circuit described herein. Cypress does not authorize its products for use as critical components in life-support systems where a malfunction or failure may reasonably be expected to result in significant injury to the user. The inclusion of Cypress' product in a life-support systems application implies that the manufacturer assumes all risk of such use and in doing so indemnifies Cypress against all charges.

Use may be limited by and subject to the applicable Cypress software license agreement.

